

## Symbols

1746 Description 1-2  
4108-13-L08 I/O Rack 2-13  
4108-13-L16 I/O Rack 2-8

## A

Active Program 3-8  
Adding a Pulse 4-32  
Adding Multiple Pulses 4-32  
Analog Offset 4-1  
Analog Output 4-1  
Analog Outputs 1-5, 2-10, 2-15, 3-5  
Analog Quantity 4-2

## B

Backplane Interlock 3-13  
Backplane Programming 3-1  
Base Revision 3-13

## C

C01 & C04 Configuration.rss 8-2, 8-3  
C01 & C04 Example.rss 8-6  
C01 & C04 Pulses.rss 8-4, 8-5  
C02 & C03 Configuration.rss 8-19  
C02 & C03 Pluses.rss 8-20  
CE Installations 2-1  
Changing Setpoints 4-33  
Channel Always ON 4-33  
Channel Copy 3-5, 4-2  
Channel Not Enabled 7-7  
Channel to Edit 4-33  
Channels 1-4  
Clear Error 3-3  
Comm Failure 7-7  
Configuration Checksum Error 7-7  
Configuration.rss 8-2, 8-3, 8-19  
Cursor Keys 3-14

## D

Decimal Point Location 3-10  
Default Program 3-13, 4-4  
Defaults 9-5  
Deleting a Pulse 4-33  
DIP Switch Settings 2-19, 2-20  
DIP Switches 2-1  
Direction of Rotation 3-10, 4-4  
Displayed Units 3-10  
Downloading PLC Program 8-9

## E

EEPROM Checksum 3-13, 4-5  
EEPROM memory 4-29  
Enable Codes 4-5  
Enable Options 4-7  
Encoder 1-2  
Encoder cable 2-7

Environment 2-1  
Error Index Number Register 3-2  
Error Messages: Keypad 7-7  
Error Messages: PL-1746-C01 Module 7-6  
Error Messages: PL-1746-C02/C03 Module 7-6  
Error Number Register 3-6  
ESC, SEL, HLP Keys 3-14  
Example.rss 8-6

## F

Fixed Response Times 5-1  
Force Outputs 3-8  
Function 7000 4-16  
Function 7001 4-16  
Function 7002 4-16  
Function 7998 4-16

## G

General Mounting & Wiring 2-1  
General Troubleshooting 7-1, 7-2  
Group Channels 1-4  
Group Offset 4-8  
Group Programming 6-2  
Groups 3-7  
Groups & Modes 1-4  
Groups & Modes Introduction 6-1

## H

Hardware Status/Error Register 3-6

## I

INC, DEC Keys 3-14  
Input File 3-1, 3-5  
Input Mapping Registers 3-6  
Input Status 4-11, 4-12  
Input Word 3-1  
Inputs 1-4  
Internal High Speed Logic 6-1  
Interrupt Enable 4-12  
Interrupts 3-6

## K

Keyboard Diagnostics 7-2  
Keyboard Quantity 3-13, 4-13  
Keypad Display 2-1  
Keypad Overview 3-14  
Keypad Wiring 2-18  
Keypad/Display, Mounting 2-1

## L

Ladder Program 3-1  
Leading Edge 3-12  
Leading Trailing Speed Comp 5-4  
Logic Inputs 3-7  
Logic Inputs Status 3-7, 4-8, 4-20

# Index

---

## M

M0 File 3-1  
M1 File 3-1  
Machine Offset 3-10, 4-14  
Machine Position 3-10  
Machine Speed 4-15  
Main Screen 4-15  
Major Revision 3-13  
Master Password 3-9  
Memory Tests 4-16  
Menu Tree 3-15  
Mode 0 Operation 6-2  
Mode 1 Operation 6-3  
Mode 2 Operation 6-4  
Mode 3 Operation 6-5  
Mode 4 Operation 6-6  
Mode 5 Operation 6-7  
Mode Assignments 6-2  
Model 3-13  
Model & Options 4-17  
Module 1-4  
Module Connections 2-2  
Module Defaults 9-5  
Module Installation 2-2  
Motion ANDing 1-5, 4-17  
Motion ANDing/Detection 3-8  
Motion Detector 4-17  
Motion Level Band 4-18

## N

Negative Speed Comp 4-44, 5-6  
Numeric Keys 3-14

## O

Offset 4-1  
Operator Enable Options 3-9  
Operator Password 3-9  
Options 3-13  
Output Assignment Screen 4-19  
Output Assignments 3-7  
Output Channels 1-4  
Output Enable 3-3  
Output Enable ANDing 3-7, 4-19  
Output File 3-1  
Output Groups 4-20, 4-21  
Output Mapping Registers 3-8  
Output Pulse Programming Appendix-1  
Output Status 3-8, 4-23  
Output Word 3-1

## P

Password 4-24  
Per Channel Enable 4-25  
Per-Channel Operator Access 3-9  
Phase Adjustment 6-1  
Pluses.rss 8-20  
Power Supply Wiring 2-1

Processor 1-4  
Program Copy 3-8, 4-25  
Program Copy Command/Status 3-8  
Program Copy Destination Program 3-8  
Program Copy Source Program 3-8  
Program Enable 3-9  
Program Initialization 8-6  
Programmable Limit Switch 1-2  
Programming Access 1-5, 4-5  
Programming Access Levels 4-6  
Programming Error Register 3-6  
Programming Preset 4-9  
Programs 1-4  
PS-4108-13-L16 I/O Rack Description 2-14, 2-16, 2-17  
Pulse Copy 3-9, 4-27  
Pulse Copy Channel 3-9  
Pulse Copy Count 3-9  
Pulse Copy Duration 3-9  
Pulse Copy Program 3-9  
Pulse Edit 3-9  
Pulse Edit Channel 3-9  
Pulse Edit Command/Status 3-9  
Pulse Edit Pulse Index 3-9  
Pulse Edit Pulse Quantity 3-9  
Pulse Modes 4-33  
Pulses 1-4, 3-10, 4-30  
Pulses Used 3-13, 4-29  
Pulses.rss 8-4, 8-5

## Q

Quick Reference 3-5

## R

Rack 1-4  
Rack Cable 2-9  
rack cable 2-14  
Rack Installation 2-8  
Rack Quantity 3-13, 4-34  
Rack Troubleshooting 7-4  
Rate Divisor 3-10  
Rate Multiplier 3-10  
Rate Setup 4-35  
Raw Resolver Position 3-1, 3-6  
Relay Mounting 2-1  
Resolver 1-2, 1-4  
Resolver Cables 2-7  
Resolver Dimensions 2-6  
Resolver, Electrical Problems 7-3  
Resolver Installation 2-5  
Resolver, Mechanical Problems 7-3  
Resolver Mode 3-10, 4-36  
Resolver Position 3-10  
Resolver Specifications 9-6  
Resolver Speed 3-10  
Resolver Troubleshooting 7-3  
Resolver Wiring 2-5  
Response Times 5-4  
Reverse Rotation 4-45  
RPM Update Rate 3-10, 4-36

# Index

---

## S

Scale Factor 1-5, 3-10, 4-37  
Sensor Lag 5-6  
Setpoint Reading 8-4, 8-5  
Setpoints 1-4  
Setting Speed Comp 5-2  
Setup Password 3-9  
Shift Count 4-40  
Shift Position 3-11, 4-38, 4-41  
Shift Register 3-11  
Shift Register Display 4-41  
Shift Window 4-42  
Sinking/Sourcing 2-11, 2-16, 2-18  
Software Version 4-43  
Solid State Relay 1-4  
Solid State Relay Mounting 2-1  
Specifications, Module 9-1, 9-2, 9-3  
Specifications, Solid State Relay 9-4  
Speed Comp Mode 3-12, 4-45  
Speed Comp, Repsonse Times 5-4  
Speed Comp, Sensor Lag 5-6  
Speed Comp, Setting 5-2  
Speed Compensation 1-5, 3-12, 4-44, 5-1  
Standard Speed Comp 5-1  
System M0 Interlock 3-1

## T

Terminal Blocks 2-1  
Timed Outputs 1-5, 3-13, 4-45  
Toggle RPM 3-10, 4-46  
Trailing Edge 3-12

## U

Utility & Example Ladder Programs 8-1

## W

Watchdog Timer Test 4-16  
Wiring Guidelines 2-1  
Wiring Inputs 2-16, 2-17