


# PL $\mu$ S<sup>®</sup> PS-6344 Series

## Programmable Limit Switch Dual Resolver Model



### Programming & Installation Manual



May 2000

**Copyright © 2000  
All Rights Reserved**

Neither this document nor any part may be reproduced or transmitted in any form or by any means without permission in writing from the publisher.

**Electro Cam**, **PL $\mu$ S**, **SLIMLINE**, and **PL $\mu$ SNET** are all registered trademarks of **Electro Cam** corp.

# Table of Contents

---

## Section 1—Introduction

Mechanical Cam Switches .....	1-1
Programmable Limit Switches .....	1-2
PS-6344 Description .....	1-3
Basic Terminology .....	1-4
PS-6344 Standard Features .....	1-4
PS-6344 Optional Features .....	1-5

## Section 2—Installation & Wiring

General Mounting & Wiring .....	2-1
Mounting Dimensions .....	2-3
Terminals & Components	
PS-6344-24-M17 .....	2-4
PS-6344-24-X16M09 .....	2-5
Controller Input Wiring .....	2-6
Output Wiring .....	2-9
Keypad Wiring .....	2-13
DIP Switch Configurations .....	2-14
Communications Wiring .....	2-16
Resolver Installation .....	2-17
Resolver Dimensions .....	2-18
Resolver Cables .....	2-19
Fuse Tester & Fuse Replacement ..	2-20
Output Transistor Replacement .....	2-21

## Section 3—Programming

Keypad Overview .....	3-1
<b>Menu Tree</b> .....	3-2
Initial Programming .....	3-3
<b>Functions (Alphabetically)</b>	
Analog Output .....	3-4
Analog Quantity .....	3-5
Channel Copy .....	3-6
Communications .....	3-6
Default Program .....	3-7
Enable Codes .....	3-8
Enable Options .....	3-10
Group Position Display .....	3-10
Increasing Direction .....	3-11
Input Status .....	3-11
Keyboard Quantity .....	3-12
Main Screen .....	3-12
Master/Slave .....	3-13
Memory Tests .....	3-14
Model & Options .....	3-14
Motion ANDing .....	3-15
Motion Detection .....	3-15
Offset .....	3-16
Output Enable ANDing .....	3-18
Output Groups .....	3-18
Output Status .....	3-20
Password .....	3-21
Per Channel Enable .....	3-22
Program Copy .....	3-22
Program Select Mode .....	3-23

## Section 3—Programming (cont'd)

Pulse Copy .....	3-23
Rate Display Mode .....	3-24
Rate Setup .....	3-25
RPM Update Rate .....	3-26
Scale Factor .....	3-26
Setpoint Use .....	3-27
Setpoints .....	3-27
Shaft Position .....	3-29
Software Version .....	3-29
Speed Compensation .....	3-30
Speed Comp Mode .....	3-31
Timed Outputs .....	3-31
Toggle RPM .....	3-32
View Resolvers .....	3-32

## Section 4—Speed Compensation

Introduction .....	4-1
Standard Speed Comp .....	4-2
Leading/Trailing Speed Comp .....	4-4
Negative Speed Comp .....	4-6
Speed Comp Guidelines .....	4-6

## Section 5—Output Grouping & Modes

Introduction .....	5-1
Mode 0 .....	5-3
Mode 1 .....	5-3
Mode 2 .....	5-5
Mode 3 .....	5-7
Mode 4 .....	5-8
Mode 5 .....	5-10
Speed Comp & Modes .....	5-12

## Section 6—Communications

Plusnet II™ Program .....	6-1
Modbus ASCII Protocol .....	6-3
Quick Reference .....	6-4
Discrete I/O .....	6-6
Registers .....	6-7

## Section 7—Troubleshooting

Controller Diagnostics .....	7-1
Keypad Diagnostics .....	7-2
Keypad Error Messages .....	7-3
Resolver Troubleshooting .....	7-5
General Troubleshooting .....	7-6
Fuse Part Numbers .....	7-7

## Appendix

Controller Specifications .....	A-1
Slimline Module Specifications .....	A-2
Transistor Output Specifications .....	A-3
Factory Defaults .....	A-3

## Index

## WARRANTY

1. Electro Cam Corp. warrants that for a period of twelve (12) months from the date of shipment to the original purchaser, its new product to be free from defects in material and workmanship and that the product conforms to applicable drawings and specifications approved by the Manufacturer. This warranty period will be extended on Distributor or OEM orders to a maximum of eighteen months to take into consideration Distributor or OEM shelf time.
2. The remedy obligations of Electro Cam Corp. under this warranty are exclusive and are limited to the repair, or at its option, the replacement or refund of the original purchase price of any new apparatus which proves defective or not in conformity with the drawings and specifications. Shipment of the claimed defective product to Electro Cam Corp. shall be at the cost of the consumer. Shipment of the repaired or replacement product to the consumer shall be at the cost of Electro Cam Corp. All claims must be made in writing to Electro Cam Corp., 13647 Metric Road, Roscoe, IL 61073 USA.
3. In no event, and under no circumstances, shall Electro Cam Corp. be liable for:
  - a. Any product damaged or lost in shipment. Inspection for damage should be made before acceptance or signing any delivery documents releasing responsibility of the delivering carrier.
  - b. Product failure or damages due to misuse abuse, improper installation or abnormal conditions of temperature, dirt or other contaminants as determined at the sole discretion of Electro Cam Corp.
  - c. Product failures due to operation, intentional or otherwise, above rated capacities as determined at the sole discretion of Electro Cam Corp.
  - d. Non-authorized expenses for removal, inspection, transportation, repair or rework. Nor shall the manufacturer ever be liable for consequential and incidental damages, or in any amount greater than the purchase price of the equipment.
4. There are no warranties which extend beyond the description on the face hereof. This warranty is in LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED INCLUDING (BUT NOT LIMITED TO) ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ALL OF WHICH ARE EXPRESSLY DISCLAIMED. Any legal proceeding arising out of the sale or use of this apparatus must be commenced within (18) months of the date of shipment from the manufacturer.